NATIONAL GEOGRAPHIC

OTORIZED


INSTRUCTIONS

STOP!

Scan the QR code and watch this short video to get started faster!



thinkbluemarble.com/motorized-models



SAFETY INFORMATION


- PLEASE READ ALL INSTRUCTIONS before use of this product. Retain this instruction manual since it contains important information, addresses and phone number for future reference.
- This toy shall only be used with a transformer (OUTPUT: DC 5V / 0.5-1.0A) for toys or a power supply for toys.
- Please disconnect from the transformer or power supply before cleaning.
- The transformer or power supply is not a toy.

examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.

The transformer used with the electric toy shall be regularly

- Misuse of transformer can cause electrical shock.
- The toy shall only be used with a transformer for toys or a power supply for toys.
- Warning: Not suitable for children under 36 months.

THIS TOY IS ONLY TO BE CONNECTED TO EQUIPMENT BEARING EITHER OF THE FOLLOWING SYMBOLS:



This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for Class B digital devices pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference to radio communications. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this toy does cause interference to radio or television reception (you can check this by turning the toy off and on while listening for the interference), one or more of the following measures may be useful:

- Reorient or relocate the receiving antenna.
- Increase the separation between the toy and the radio or the TV.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced TV-radio technician for help.

CAN ICES-003(B)/NMB-003(B)

When this product has reached the end of its useful life, it should not be disposed of with other household waste. The Waste Electrical and When this product has reached the end of its useful life, it should not be disposed of with other household waste. The Waste Electrica Electronic Equipment Regulations require it to be separately collected so that it can be treated using the best available recovery and recycling techniques. This will minimize the impact on the environment and human health from soil and water contamination by any hazardous substances, decrease the resources required to make new products and avoid using up landfill space. Please do your part by keeping this product out of the municipal waste stream! The "wheelie bin" symbol means that it should be collected as "waste electrical and electronic equipment". You can return an old product to your retailer when you buy a similar new one. For other options, please contact your local council.

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

© National Geographic Partners LLC. All rights reserved. NATIONAL GEOGRAPHIC and Yellow Border Design are trademarks of National Geographic Society, used under license. © Blue MarbleTM All rights reserved. Blue MarbleTM and the Blue Marble logo are trademarks of JMW Sales, Inc.

Customer Service: 1 (541) 708-6738 · help@thinkbluemarble.com JMW Sales, Inc., dba Blue Marble™ • 101 A Street, Ashland, OR 97520 USA EU Responsible Person (Please contact for regulatory inquiries only.) Blue EU RP, Kroonwiel 2, 6003 BT Weert, The Netherlands


IMPORTANT BUILDING TIPS


Punch out pieces one section at a time and arrange them in order on your workspace.


 Make sure pieces are fully inserted into one another. You may need to apply a bit of pressure to ensure a secure fit.

Hook Icons

 When you see one of the hook icons shown below, it means you will be building directly onto the identified base support rod.










1 HEAD


STEP BY STEP





Note: Hold 1A in place on the support rod while completing the next steps.


















P NECK 8


PIECES NEEDED







ARMS


STEP BY STEP















Note: Pegs 2D, 2E, 2F, and 2G are designed to rest loosely in the slots in 2B. This is to allow the torso to move while remaining structurally sound. The following step will secure these pieces and prevent them from falling out.













Note: Slide the neck pieces into the head pieces as shown in the "Top View" image above. Make sure the holes in the neck and head pieces are aligned so **2I** can slide all the way in.












E) TORSO





STEP BY STEP





Note: Hold **3A** in place on the support rod while completing the next steps.
















TORSO continued




Note: The flat end of piece 3F should rest flush with the back of piece 3E.



Note: Pieces **3I** and **3J** are designed to rest loosely on piece **3F**. This is to allow the legs to move back and forth. Steps in the following section will secure these pieces and prevent them from falling out.




Note: The build from the last two steps will rest loosley in piece **3M**.




Note: The flat end of piece 3H should rest flush with the back of piece 3G.





Note: Pieces **3K** and **3L** are designed to rest loosely on piece **3H**. This is to allow the legs to move back and forth. Steps in the following section will secure these pieces and prevent them from falling out.





Note: The build from the last two steps will rest loosley in piece 3N.

















Note: Slide the neck pieces into the torso pieces as shown in the "Top View" image above.







Note: Make sure the holes in the neck and torso pieces are aligned so 30 can slide all the way in.










(A) LEGS




STEP BY STEP













Note: Push 4B to the left until the notch slides into the space on piece 3H and locks in place.











Note: Push 4E to the right until the notch slides into the space on piece 3F and locks in place.





3 LOWER TORSO




STEP BY STEP

Note: Pieces 5B and 5D may be tricky to place, but their positioning allows the T. rex's tail to move side to side. Piece 5A has notches to hold each of the previously noted pieces, while 5C and 5E secure them in place.






Note: Make sure piece **5B** is pushed all the way onto **3C** and **3B** to allow your T. rex to move. Some force may be necessary here, but be careful! The wood is delicate and may break if placed under too much strain.







Using Your Motorized Model

- Plug the small end of the supplied Micro-USB cord into the port on the side of the base.
 Connect the other end to a suitable USB port (not included).
- Press the power button once to make your model move, and again to turn it off.
 Note: To optimize motor life, do not run for prolonged periods of time. The model's motor will automatically turn off after 1 hour.
- 3. Press the light button once to turn on the light.
- Press the color button once to enter color-change mode. To cycle through a selection of solid colors, press the color button additional times.
- 5. To dim the light, press the light button additional times. Continue pressing to turn the light off.

Add a Decal to your Model Base

- 1. Remove the protective film from the front of your model base and dispose.
- Peel the backing off the included decal and align it with the front of your base. Start at one end and roll the decal on for optimal placement.